

Hydrotek DIY bucket test

- 1 Fill pool to your normal level, ensure pool pump is switched off.
- 2 Fill bucket with pool water to approximately 5cm from top.
- 3 Leave the bucket on first step of pool, marking the water level on the inside and outside of bucket.
- 4 Wait 24 hours to measure the change in water levels on both markers. If the difference on the outside is greater than the inside marker, there is a leak.



Contact us to discuss the right leak detection service for you **0480 27 44 28**

info@hydrotekleaksolutions.com